(EN) ENGLISH

Important: *Read these instructions for use carefully. Familiarize yourself with the appliance before connecting it to its gas container. Keep these reference.* **USE OUTDOORS ONLY**

FOR YOUR SAFETY

If you smell gas:
1. Do not attempt to light appliance.
2. Extinguish any open flame.
3. Disconnect from fuel supply.
Do not store or use gasoline or any other liquids with flammable vapors in the vicinity of this or any other appliance.

CARBON MONOXIDE HAZARD

DANGER

This appliance can produce carbon monoxide which has no odor.
Using it in an enclosed space can kill you.
Never use this appliance in an enclosed space such as a camper, tent, car, or home.

If there is a leak on your appliance (smell of gas), remove it to a well-ventilated, flame-free location. Leave the leak may be detected and stopped. Check for leaks on your appliance periodically using a mixture of soap and water. Use only USE IN WELL VENTILATED AREA. **Accessible parts may become very hot. Keep young children away.** JOULE Alpinist Series Gas Cartridge Stove is intended outdoor, at least 1m away from any combustible materials. Do not move, lift, or tilt JOULE while burner is lit. Flaring may occur.

Gas category: Butane under vapor pressure. Use only with 100g/230g Jetboil Jetpower Isobutane/Propane Gas Cartridge (sold separately). Canister connection is compatible with EN417 or AS2278 standard. It may be hazardous to attempt to fit other types of gas containers. **Gas Heat:** 2,200 Btu/hr **Gas consumption:** 215 g/h (3 kW / 10.000 BTU/h / 11 MJ/h)

ASSEMBLY

Refer to the following diagramme when assembling and operating JOULE:
1. Fully assembled unit
2. Burner, control and valve
2.1. Control valve
Remove packed cosmetic foam cover (6). Unfold the ball from the valve body (2.1). Check that control valve is closed (3.1) or turned fully clockwise. Remove O-ring (2.2) in place and in good condition before connecting to gas cartridge. Do not use this appliance if it has damaged or worn seal. Screw the valve onto the gas cartridge (sold separately) Connect cartridge (see 4.1)
Hold cartridge inverted and screw it securely (clockwise) to the burner base (4.2). Hand tighten only. Do not overtighten. Check for leaks before assembling and operating. Use soap and water solution, not a flame. Test for leaks. Turn the cory button (1.2) allow attachment of optional Joule Alpinist Pot. Ease of use for Joule Alpinist Series Cooking System.

OPERATION WARNINGS

Do not leave Jetboil JOULE unattended while in operation. Use only with Jetboil JOULE cooking system intended for use with Joule components exclusively.
Always change fuel canister in a well ventilated area. Keep away from any sources of ignition, such as open flames, pilots, electric fires, and away from other people. **If you smell gas or if see gas escaping in a well ventilated area, immediately close the valve on the burner.** Confirm control valve is closed (turn clockwise), and fuel canister is screwed on tightly. If smell of gas persists, disconnect fuel canister and refer to troubleshooting section. Do not, under any circumstances, attempt to make fuel canister or any other fuel canister. DO NOT try or cook foods with low moisture content. Use low flame settings when heating liquid foods to avoid boil-over. **Heavy liquids near maximum capacity, use only low flame settings and exercise caution to prevent boil-over.**

OPERATING INSTRUCTIONS

Ignite burner before placing vessel on burner. Keep burner at arm's length, away from face and body. Ignite burner with a match or gas lighter. **Do not attempt to ignite burner** if flammable vapors or liquids while lighting the burner. **It can cause an explosion or fire. Lightpot** **Be sure** **the** **gas** **cartridge** **is** **not** **hot.** If gas does not ignite, wait 1 minute for more information. To light, press igniter button (2.3) while slowly turning control valve (3.1) counterclockwise. Release control knob when burner lights. Hold control knob down for about flame to low-to-medium setting. Do not, under any circumstances, turn control knob all the way to full flame. Turn control knob to adjust flame. Check flame for stability. Turn off control knob when finished. Turn control knob clockwise (3.1) to extinguish flame. Do not force control knob beyond stop. Check flame for stability. Turn off control knob when finished. Turn control knob clockwise (3.1) to extinguish flame.

STORAGE AFTER USE

EXPOSED METAL PARTS MAY BE HOT.
Hold vessel by handle (1.1) and vessel (1.2), and by base (2.4) to detach vessel from burner base (5), by twisting counterclockwise then lifting to separate.
ALWAYS CHECK THAT THE BURNER (2.2) IS EXTINGUISHED BEFORE DISCONNECTING THE FUEL CANISTER (4.2). Unscrew fuel cartridge from burner base (5). Fold Valve ball up into burner base (2.1). Place burner base in bottom of vessel with burner (2.2) facing up. Replace Lid. Fold handle over lid. Do not store if during heated food. Do not store if food or water is over vessel. (6.1).
Always disconnect fuel canister after use. Fuel canisters can explode. Store fuel canisters outdoors in a dry, well-ventilated area, away from heat, and out of the reach of children.
Cleaning Instructions: Wipe Joule Alpinist Series Cooking System components to clean - they will damage the vessel. Only wash the vessel by hand with soapy water.

MAINTENANCE AND REPAIR INSTRUCTIONS

Do not modify this appliance. This appliance must only be serviced by an authorized service technician. Contact your local dealer, distributor, or Jetboil for parts and/or service. If stove is operating poorly or is damaged, turn off the gas supply, disconnect the fuel canister and refer to the instructions and recommended use, may be hazardous and will void the warranty. If an issue cannot be resolved,