




Old Town Canoe
 35 Middle Street
 Old Town, Maine 04468
 207-827-5513
 www.oldtowncanoe.com

<h1>Kayak Paddle Holder Kit</h1>		
Kit part# 01.1331.1987	Revision 3/03	Page 1 of 2



Cord

Pad Eye

Hook

Rivet

Backup Washer

Kit Contents:

Quantity	Description	Part Number
2	Pad Eye	1315.0430
2	Hook	1315.0165
6	611 Rivet	1315.1560
6	Backup Washer	1315.1568
1	36" Shock Cord	1315.0709

Tools Required:

Drill	Rivet gun	Marker
3/16-inch drill bit	Tape measure	Masking tape

Note: The basic layout for the paddle holder is shown below. The ideal location for your paddle holder is determined by the width of your kayak, your paddling position, and your height and arm length. It is very important to sit in your boat first to locate the pad eyes and hooks where they will not be contacted by your hands while paddling.



Step 1. Mark pad eye locations

- Locate the rear pad eye and hook approximately even with your hip when you are sitting in the kayak. Mark locations.
- Locate the front pad eye and hook 24" to 26" in front of the rear pad eye and hook. Mark locations.



Old Town Canoe
35 Middle Street
Old Town, Maine 04468
207-827-5513
www.oldtowncanoe.com

Kayak Paddle Holder Kit

Kit part# 01.1331.1987 Revision 3/03 Page 2 of 2

Step 2. Paddling Test

- Tape the pad eyes and hooks in place temporarily with the masking tape, and get in the kayak on the ground with your paddle.
- Check that the front pad eye and hook is beyond the sweep of your hand as you paddle. Check that the rear pad eye is far enough inboard to avoid hand contact. Check that the paddle will lie on the deck and not interfere with any other parts of the kayak or rigging.
- Adjust locations as necessary and recheck.

Step 3. Attach pad eyes and hooks

- Drill 3/16-inch holes at the four marked spots. Place rivet through each pad eye and hook and into the drilled holes.
- Align the pad eye as desired (recommended parallel to edge of deck) and drill the second hole using the pad eye as a template. Place rivet through each pad eye and hole.
- Reach under deck and hold washer on one rivet and against the underside of deck. Set rivet with rivet gun. Repeat for each rivet.

Step 4. Rigging the shock cord

- Knot one end of shock cord. Thread through the pad eyes so that the knots are on the opposite side from the hooks. Loosely tie the second knot so that the cord is slightly taut between the two pad eyes.
- Check and adjust the shock cord tension by putting your paddle in place between pad eyes and hooks and stretching the cord up over the paddle shaft and onto the hooks. Cord should hold paddle firmly in place but it should not require excessive effort to hook and unhook. Adjust the knot location, if needed.
- Tighten second knot and cut off any excess shock cord. The ends may be melted to prevent fraying.