

**Saranac Seat
Back Kit
Instruction**



125 Gilman Falls Road
Building B
Old Town, ME 04468 USA
800-8-KAYAKS
www.oldtowncanoe.com

Please read kit instructions carefully prior to installation.

Many of our kit installations can be viewed at www.youtube.com/oldtowncanoeandkayak

KIT CONTENTS			
Ref. Letter	Part Number	Description	Quantity
A	01.1315.2467	Seat Back Saranac	1 EA
B	01.1315.0491	Saranac XT Seat Bracket	1 EA
C	01.1315.2813	Seat Adjustment Ball	1 EA
D	07.2479.0000	Cleat Clam CL 203	1 EA
E	01.1315.1564	Rivets-AA611 Black	2 EA
F	01.1315.1568	3/16 Backup Deck Washer	2 EA
G	07.3404.0000	Saranac Seat Pad	1 EA
H	01.1315.3590	¼" Panel Fasteners	5 EA



Before getting started we recommend sorting out and separating the parts for easy access during assembly.

Rev. A
Issue Date: 07/15/2011
Doc. # K-01.1331.1225
Page 1 of 5

**Saranac Seat
Back Kit
Instruction**



125 Gilman Falls Road
Building B
Old Town, ME 04468 USA
800-8-KAYAKS
www.oldtowncanoe.com

Please read kit instructions carefully prior to installation.

Many of our kit installations can be viewed at www.youtube.com/oldtowncanoeandkayak

Tools Required: Flat Head Screw Driver, Drill, 13/64" Drill Bit, and Pop Rivet Tool

1. Locate the Saranac Seat Bracket (B); insert it in one of the two seat bracket holes on the stern side of the seat as shown in Fig #1. Now push the Seat bracket (B) through to the second hole and pull it up through as shown in Fig# 2.



Fig# 1



Fig# 2

2. Locate the Seat back (A) and in the full back position insert one side of the Seat back (A) into the seat bracket (B) as shown in Fig # 3. Now using your flat head screw driver for leverage pop in the other side of the seat back as shown in Fig# 4.



Fig # 3



Fig# 4

Rev. A
Issue Date: 07/15/2011
Doc. # K-01.1331.1225
Page 2 of 5

**Saranac Seat
Back Kit
Instruction**



125 Gilman Falls Road
Building B
Old Town, ME 04468 USA
800-8-KAYAKS
www.oldtowncanoe.com

Please read kit instructions carefully prior to installation.

Many of our kit installations can be viewed at www.youtube.com/oldtowncanoeandkayak

3. Next find the Cleat Clam (D) and rest it in the pocket on the right side of your seat with the high end facing the bow as shown in Fig# 5, using the clam cleat as a jig drill two holes with a 13/64" drill bit and install the two Rivets (E), Place a back up deck washer (F) onto each rivet end and pop the rivets with a pop rivet tool as shown in Fig# 6.



Fig# 5



Fig# 6

4. Take the rope that is attached to the seat back (A) on the right side and feed it through the cleat clam (D) on the right side of the seat, Locate the seat adjustment ball (C) then feed the same end of the rope through it and tie a knot at the end of the rope as shown in Fig# 7.



Fig# 7

Rev. A
Issue Date: 07/15/2011
Doc. # K-01.1331.1225
Page 3 of 5

**Saranac Seat
Back Kit
Instruction**



125 Gilman Falls Road
Building B
Old Town, ME 04468 USA
800-8-KAYAKS
www.oldtowncanoe.com

Please read kit instructions carefully prior to installation.

Many of our kit installations can be viewed at www.youtube.com/oldtowncanoeandkayak

5. Locate the rope on the left hand side of the seat back (A) and insert it down through the bow most left hand hole in the seat. Now tie a double knot in the end of the line to keep it from pulling back through the seat hole as shown in Fig # 8. Your finished seat back should look like Fig# 9. You can adjust your seat back to your desired angle by adjusting the rope connected to the seat adjustment ball (C) on the right side.



Fig# 8



Fig# 9

6. Locate the Saranac Seat Pad (G) and place on seat base so that the holes in the seat base line up with the pad. Push the 1/4" Panel Fasteners (H) into the five holes to complete the installation as shown in fig# 10.



Fig# 10

Rev. A
Issue Date: 07/15/2011
Doc. # K-01.1331.1225
Page 4 of 5