20lb Tank Hose

Eureka!

Eureka!

Instructions for Use

Johnson Outdoors Gear, Inc. 625 Conklin Road Binghamton, NY 13903 1.800.847.1460 IOHNSON

www.eurekatent.com

- Use only with Jetboil or Eureka! regulated propane stoves.
 - Must be used in conjunction with Regulator provided with stove.
 - Insure that all threaded connections are completely secure/threaded before operating system.

 Operate steve on a horizontal system of least 1m/2 2ft away from any completible materials.
 - Operate stove on a horizontal surface, at least 1m/3.3ft away from any combustible materials.

 Viscounist to about foolering any year anglescent do it extends to be about a detact to be a series.
 - If you wish to check for leaks on your appliance, do it outside. Do not try to detect leaks using
 a flame, use soapy water. Put some soapy water on the gas connection points, if a bubble is
 found, there is gas leakage.
- Check that seals are in place and in good condition before connecting to gas flow.
- Always disconnect from fuel source after use. Store fuel canisters outdoors in a dry, well-ventilated area, away from heat, and out of reach of children.

Tuyau pour bouteille de propane 9 kg

Mode d'emploi

- Utilisez ce tuyau uniquement avec des poêles au propane réglementés de marque Jetboil ou Eureka!
- Doit être utilisé en conjonction avec le régulateur de carburant fourni avec le poêle
- Assurez-vous que tous les raccords filetés sont complètement vissés et sécurisés avant de faire fonctionner le système.
- Faites fonctionner le poêle sur une surface horizontale à une distance d'au moins 1 mètre (3,3 pieds) des matières combustibles.
- Si vous désirez vérifier la présence de fuites dans votre appareil, faites-le à l'extérieur. N'essayez pas de déceler les fuites avec une flamme; utilisez plutôt de l'eau savonneuse. Appliquez de l'eau savonneuse sur les points de connexion à la source de gaz. Si vous trouvez une bulle, voilà une fuite de gaz.
- Vérifiez toujours que les joints d'étanchéité sont bien en place et en bon état avant de faire la connexion au débit de gaz.
- Débranchez toujours l'appareil de la source approvisionnement en carburant après chaque utilisation. Entreposez les cylindres de carburant à l'extérieur dans un endroit sec et bien aéré, loin de la chaleur et hors de la portée des enfants.