



- 1** Place folded cot on ground like shown.




- 2** Unfold cot rails by swinging them outward.

- 3** Pull upward on cot rails to deploy legs.

- 4** Place cot upright on the ground.



- 5** Engage both leg locks located along the rails.



- 6** Reverse steps to collapse cot.

QUESTIONS?

Johnson Outdoors Gear, Inc.
USA: 1-800-572-8822
www.eurekacamping.com

Johnson Outdoors Canada
Canada: 1-800-263-6390
www.eurekatentscanada.com

FURNITURE CARE

- Weight limit: 300lbs
- Keep away from open flame
- Use on level ground
- Use caution to avoid injuring fingers when opening/closing

WARRANTY

- Your Eureka! furniture is covered by a one year warranty. For more details please visit the website or contact customer service.