



TALON WIRELESS FOOT SWITCH GUIDE

› How to pair a Legacy Talon Wireless Foot Switch (2016 & Prior)

BEFORE YOU BEGIN: The MODE button acts like a toggle switch to operate either the left, right, or both Talons simultaneously. The LED's will illuminate to indicate which mode is active. If you are operating only 1 Talon, you will need to learn the switch to the Talon (left or right) that you wish to operate. If you are running 2 Talons, you will need to learn the switch 3 separate times. 1. Left 2. Right and 3. Both

1. Stow the anchors by pressing the Auto UP buttons on the Talons to be controlled.
2. Press the MODE button on the foot switch, and note that either the LEFT, RIGHT, or both LED's will illuminate. This is the Talon that is now ready to learn.
3. Press and continue to HOLD the Auto UP button on the Talon, and then press either the 'UP' or 'DOWN' button on the footswitch one time.
4. A series of 3 beeps will be heard, indicating the footswitch has been programmed to that Talon.
5. Release the Auto UP button on the Talon after the 3 beeps begin.
6. Repeat steps 2-5 to program the other Talon to the other UP button.
7. When learning the switch to both Talons, you must be in 'both' mode and then repeat steps 3-5 once to each Talon.

NOTE: Talon can store up to 10 remotes including the wireless footswitch.

FOR MORE INFORMATION, VISIT MINNKOTAMOTORS.COM