



SCUBAPRO

GALILEO HUD COMPATIBLE MASKS



MASK		HOLDER	1 - MOUNT USING UPPER SLOT # 2 - MOUNT USING LOWER SLOT #
	D-MASK	Shipped with D-Mask	-
	SPECTRA	Shipped with GALILEO HUD	1 *
	SYNERGY TWIN**	Shipped with GALILEO HUD GALILEO HUD	2
	SPECTRA MINI	Shipped with GALILEO HUD	2
	ZOOM**	Available to buy separately	-
	VIBE 2	Shipped with GALILEO HUD	2
	ECCO**	Shipped with GALILEO HUD	2 *
	PRO EAR	Shipped with GALILEO HUD	2
	FUTURA 1	Shipped with GALILEO HUD	1 *
	FRAMELESS	Available with integrated holder	-

The holder has 2 slots, one above the other. The one you will use to thread your cable ties depends on your mask.

(1) If the bridge of the nose aligns with the higher point, use the upper slot.

(2) If the bridge of the nose aligns with the lower position, use the lower slot.

See the Galileo HUD Manual - 1.3 Mounting the holder to the mask - step 6.

* Shorten the tiny legs as needed with the side cutters.

See the Galileo HUD Manual - 1.3 Mounting the holder to the mask - step 2.

** Also applies to Combo (Mask & Snorkel set)

