

Surface

Ne

SCUBAPRO

BUTTONS

Press The act of pressing and releasing one of the buttons.

Press-and-Hold

The act of pressing and holding one of the buttons for 1 second before release.



TURN ON: Press-and-hold the right button.

GO BACK: Press-and-hold the right button.

RETURN HOME: Press-and-hold right & left buttons simultaneously.



S		Button functions at the SURFACE in SCUBA and GAUGE modes		
נוסע		LEFT BUTTON (Menu)	MIDDLE BUTTON (Log)	RIGHT BUTTON (Light/Dim)
Functions	Press	Main menu	Logbook	Backlight
	Press-and-Hold	Oxygen setting	Gas summary table	Compass
		Button functions while DIVING in SCUBA mode		
Functions		LEFT BUTTON (Book)	MIDDLE BUTTON (More)	RIGHT BUTTON (Light/Dim)
	Press	Bookmark + stopwatch reset	Alternate window in sequence	Backlight
	Press-and-Hold	Start manual gas switch	Alternate display in sequence; Compartment saturation; Dive profile/pictures	Compass
		Button functions while DIVING in COMPASS mode		
		LEFT BUTTON	MIDDLE BUTTON (Set)	RIGHT BUTTON (Exit)
	Press	Set bookmark and reset stopwatch	Set bearing	
	Press-and-Hold		Erase set bearing	Exit compass mode



For more information and to view this card in other languages, visit www.scubapro.com

SELECT FROM FOUR DIVE SCREEN OPTIONS - Light, Classic, Full, Graphical

(Go to Personalization > Screen configuration)

You can also rotate the screen to have the buttons positioned at the bottom of the screen.

LIGHT SCREENS IN FOUR DIFFERENT COLOR OPTIONS



CHECK YOUR BATTERY

Your G2 is powered by a rechargeable Li-lon battery.
 Always check the battery capacity before each dive.
 If the battery warning appears, charge the battery.

WARNING!

Once your G2's battery reaches the end of its lifetime, it can only be replaced by an authorized SCUBAPRO service center.

Do not open your G2 or try to replace the battery yourself!

Opening the G2's housing or the metal cap on the side of the G2 will VOID YOUR WARRANTY.

Changing the battery must be done with particular care in order to prevent water from seeping in.

The G2's warranty does not cover damages due to the improper placement of the battery,

or the incorrect closing of the battery cap.

G2 Quick Use Guide

PAIRING YOUR TRANSMITTER

METHOD 1 AUTOMATIC

- Mount the 1st stage with the transmitter attached on a full tank.
- Turn on your G2, make sure it is displaying the time-and-date screen, then place it near the transmitter (as shown on the right) and open the tank valve.



METHOD 2 MANUAL

- Mount the 1st stage with the transmitter attached on a full tank.
 Turn on your G2.
- From the time-and-date screen press the left button to enter the Main Menu.
- Scroll to Other Settings.
- Press the right button to enter.
- From Other Settings menu scroll down to Gas Integration.
- Press the right button to enter.
- From Gas Integration menu scroll to Pairing.
- Press the right button to enter.
- Open the tank valve, and you are ready to pair.

- Using either method, once pressurized the transmitter will send a pairing sequence to your G2.
- When it receives this information, the display will show a list of tank designations.
- Scroll to Tank TI. (Tank TI is always the main tank you start your dive with.)
- Press the right button to save your selection.
- Your G2 will confirm the pairing with the message "PAIRING TO TI SUCCESSFUL".
- At that point the tank pressure will appear on your G2's display, and you're ready.

HOW TO POSITION AND USE THE DIGITAL HEART RATE MONITOR

- Position your Digital Heart Rate Monitor as shown on the right.
- Adjust the soft strap so that it is comfortable to wear but snug enough so that it stays in place.
- The Digital Heart Rate Monitor must be worn directly against the skin.
- Moisten the electrode areas if your skin is dry or when diving in a drysuit.
- The maximum operating depth for the Digital Heart Rate Monitor is 393ft/120 m.

TO ACTIVATE THE HEART RATE FUNCTION ON YOUR G2

- From time-and-date screen press MENU to enter Main Menu
- ∎ Scroll to **Personalization** & press ENTER.
- Scroll to Workload & press ENTER.
- Select Heart Rate & press right button to save.

- Advance to Max HR set value & press right button to save. ■ Advance to Base HR– set value & press right button to save.
- Advance to Use skin temp. set to ON & press right button to save.
- ∎ Heart Rate & Skin Temperature functions are now activated.

G2 Quick Use Guide

